

Get oriented



Quick start: Surface Pro 4



Pull it apart

The screen detaches so you can use it as a tablet.

It's connected with magnets



Just pull them apart...



...or you can always fold the keyboard over



A simple, powerful pen

Top button

What this button does depends on what you're doing and how many times you click it.

- Click once to open Windows Ink Workspace, where you can create Sticky Notes, draw in the sketchpad, or take notes on a webpage or photo using screen sketch.
- Double-click to take a picture of your screen and open it in screen sketch.
- Click and hold to open Sticky Notes so you can jot down an idea before you forget it.
- Change what the top button does in Settings > Devices > Pen & Windows Ink.



Magnetic strip

Attach the pen to the side of your screen for safekeeping.

Right-click button


The end of the magnetized strip works like the right-click button on a mouse.

Put the pen to work

Draw, take notes, do math, and more. Portrait or landscape, lap or tabletop.

Select the Pen  icon

This opens the Windows Ink Workspace, where you can create Sticky Notes, sketch on a blank screen, or draw on an image on the screen.



Say goodbye to your bulky PC tower

With the optional dock, you can use the Surface Pro 4 like a traditional desktop.

The dock has ports for all your needs
4 USB, 2 Mini DisplayPort, Ethernet, and a
headphone jack.



Connect what you need
Monitor, wireless keyboard
and mouse, external hard
drive, and more.